
PC RUNNING SDR CONSOLE
HF ANTENNA
SDR RECEIVER
RSPDUO
EME222 SDR
RX ANTENNA
SWITCH
+13.8VDC 100mA
IC-7300 TRANSCEIVER
ACC TX OUT